

Robomow®

Your robot. Our expertise.

How to restart One Time Setup in 'S' model.

- 1 Press and hold STOP + Down arrow buttons together more than 4 seconds.



How to restart One Time Setup in 'C' model.

- 2 Press and hold STOP + Setting + Left arrow buttons together more than 4 seconds.

